



Instructions for ARRI® OMNIBAR®

Please also refer to the luminaire instructions regarding use of accessories.

SNAPBAG for ARRI Omnibar

2ft Version: L2.0056269 / SBA0L2SB

4ft Version: L2.0056270 / SBA0L4SB

1. ATTACH ARRI PIN TO BACKPLATE



2. ADJUST ANGLE



Pull and attach outer velcro straps to narrow.

3. ATTACH DIFFUSION



4. OMNIBAR CONTROL ACCESS WINDOW



5. MOUNTING POINT FOR SAFETY CABLE



Always secure the accessory with a suitable safety cable from falling when the primary mounting method fails.

AIRGLOW LANTERN for ARRI Omnibar

2ft Version: L2.0056267 / SBA0L2F

4ft Version: L2.0056268 / SBA0L4F

1. PUMP UP



Pump up with Boston valve air pump

2. INSERT OMNIBAR



Insert the OMNIBAR into the elastic spill lip

3. ATTACH VELCROS



Attach the fixture with two Velcro Straps

4. SPILL COVER



Install the optional rollable Spill Covers with velcos

5. MOUNTING POINT FOR SAFETY CABLE



Always secure the accessory with a suitable safety cable from falling when the primary mounting method fails.

SAFETY INSTRUCTIONS

WWW.DOPCHOICE.COM/INSTRUCTION

